2600 INSTALLATION INSTRUCTIONS

The 2600 is used to detect the presence of water and to provide a relay signal for controlling external devices. The switch operates on 12 Volts DC and functions as a Normally Closed Sensor, for a Normally Closed Loop system. The Red and Black wires are for powering the switch while the White and Green wires are the relay control wires.

wire for those panels that require end-of-line resistance. selected Closed Loop terminal. A resistor can be connected in series with either the Green or White For installation on an alarm panel, the Red wire is connected to the auxiliary 12 volt supply and the Black wire is connected to negative. The Green and White wires can then be connected to any pre-

For applications other than alarm panels, see switch specifications or contact factory.

corrosion or damage the sensor should be replaced. After installation these units should be tested with water and inspected annually. If there is any

	SPECIFICATIONS	CATIONS	
Power Requirements:		Wire Connections:	
Operating Voltage	12 Volts DC	Red	+12 volts DC
Operating Current	10 mA	Black	-Ground
		Green	Relay Contact
		White	Relay Contact
Contact Characteristics:			
Contact Resistance	100mΩ		
Switching Voltage	200 Volts DC Max		
Switching Current	500 mA Max		
Carry Current	1 Amp Max		
Power	10 VA Max		7/12/200

7/12/2007